
Universal Electronics/Innovative Systems Potenza ST Backlit Remote



Programming

Quick Setup STB Codes

-Hold SETUP plus the corresponding digit key, until the STB device key blinks twice:

- Digit 1 - Legacy Amino Global
- Digit 2 - Legacy Amino IR Band 1
- Digit 3 - Legacy Amino IR Band 2
- Digit 4 - Legacy Amino IR Band 3
- Digit 5 - Legacy Amino IR Band 4
- Digit 6 - ADB
- Digit 7 - Entone/Amino

Manual Code Entry

-Hold SETUP until the STB key blinks twice. Enter the four-digit code. Verify that the STB key blinks twice to confirm the code is stored.

- Legacy Amino - 1 8 9 8
- ADB - 2 2 5 4
- IS-5112W (uses Motorola code) - 1 3 7 6
- Entone/Amino - 4 4 3 7

UEI Simple Set Device Codes

-These codes are used to quickly program the TV, AUD, DVD, and VCR device keys for popular brands.

- Hold SETUP until the device key blinks.
- Press the device key you wish to program. The device key should stay lit.
- Point the remote at your device. Press and hold the digit corresponding to the device brand, until the device turns on/off. (Usually happens very quickly)
- The remote should now be programmed for your device.



TV

DIGIT | BRAND

1	Insignia
2	LG
3	Panasonic
4	Philips/Magnavox
5	Samsung
6	Sanyo
7	Sharp
8	Sony
9	Vizio
0	Westinghouse

DVD/VCR

DIGIT | BRAND

1	Insignia
2	LG
3	Panasonic
4	Philips/Magnavox
5	RCA
6	Samsung
7	Sharp
8	Sony
9	Toshiba
0	Vizio

Audio

DIGIT | BRAND

1	Bose
2	Denon
3	LG
4	Onkyo
5	Panasonic
6	Philips
7	Pioneer
8	Samsung
9	Sony
0	Yamaha

Master Power

- Hold SETUP until the device key blinks twice
- Enter 9 9 5
- Press POWER
- Press the device keys you want to include in the Master Power programming
- Hold SETUP until the device key blinks twice

Unlock STB Key

- Hold SETUP until the STB key blinks twice
- Enter 9 8 2
- STB key will blink four times (unlocked)
- STB key can now be programmed

Unlock AUD, DVD, and VCR Keys

- Hold SETUP until the device key blinks twice
- Enter 9 9 2
- Press the device key twice
- The device key should blink twice. It can now be programmed.

Example: To unlock the DVD device key, press [SETUP] > 9 9 2 > DVD > DVD.



Current Programming

This will show you what code is currently programmed on the remote.

- Press and hold the Setup key until the STB key blinks twice
- Enter 990
- STB key will blink twice
- Press 1 and count the blinks = 1st number in the code
- Press 2 and count the blinks = 2nd
- Press 3 and count the blinks = 3rd
- Press 4 and count the blinks = 4th
- Put the numbers together and you have the 4-digit code

